Marshall

Broadcast A/V Division

CV574-WP

All-Weather NDI HX3 POV Camera



User Manual

Table of Contents

Copyright Information 1

Chapter 1: Safety Instruction 2

Chapter 2: Package Contents 3

Chapter 3: Connecting Camera to Network 4

Chapter 4: Web Interface Settings 5

Chapter 5: Upgrade 14

Warranty 14

Copyrights © Marshall Electronics, Inc. All rights reserved.

Copying, reproducing or transmitting this file is not allowed if a license is not provided by Marshall Electronics, Inc., unless copying this file is for the purpose of backup after purchasing this product.

In order to keep improving the product, Marshall Electronics, Inc. hereby reserves the right to make changes to product specifications without prior notice. The information in this file is subject to change without prior notice.

To fully explain or describe how this product should be used, this manual may refer to names of other products or companies without any intention of infringement.

Disclaimer of warranties: Marshall Electronics, Inc. is not responsible for any possible technological, editorial errors or omissions, nor responsible for any incidental or related damages arising from providing this file, using, or operating this product.

Chapter 1: Safety Instructions

Always follow these safety instructions when setting up and using this product:

1. Operation

1.1 Please use the product in the recommended operating environment where temperatures are between -10˚C ~ 50˚C, and humidity level is 70% or below.

1.2 Do not use this product near water or source of heat.

1.3 Use attachments only as recommended.

1.4 Use the type of power source indicated on this product. If you are not sure of the type of power available, consult your distributor or local electricity company for advice.

1.5 Always take the following precautions when handling this connection as failure to do so may result in sparks or fire:

- ☐ Ensure the plug is free of dust before inserting it into a socket.
- ☐ Ensure that the plug is inserted into the socket securely.

1.6 Do not overload the wall socket, extension cords, or multi-way plug boards as this may cause fire or electric shock.

1.7 Do not block the slots and openings in the case of this product as they are meant to provide ventilation and prevent this product from overheating.

1.8 Except as specifically instructed in this User Manual, do not open or remove covers, Otherwise, you may be exposed to dangerous voltages and other hazards. Refer all servicing to licensed service personnel only.

1.9 Unplug this product from the wall outlet and refer servicing to licensed service personnel when the following situations happen:

- ☐ If the power cords are damaged or frayed.
- ☐ If liquid is spilled into the product or the product has been exposed to rain or water.

2. Installation

2.1 For security considerations, please make sure the standard hanging rack you purchased, is in line with UL or CE safety approbations and installed by a certified technician approved by agents.

3. Storage

3.1 Do not place the product where the cord can be stepped on as this may result in fraying or damaging the lead or the plug.

3.2 Never push objects of any kind through cabinet slots. Never allow liquid of any kind to spill into the product.

3.3 Unplug this product during thunderstorms or if it is not going to be used for an extended period.


3.4 Do not place this product or accessories on top of vibrating equipment or heated objects.

4. Cleaning

4.1 Unplug all the cables before cleaning. Use a damp cloth for cleaning. Do not use liquid or aerosol cleaners.

Chapter 2: Package Contents

Camera:



Accessory:

- 12 Volt DC 2 Amp power adapter with 4 interchangeable plugs



Chapter 3: Connect Camera to Network

CV574-WP camera comes with DHCP enabled by default.

If the camera is connected to a router or DHCP enabled network device, it will be assigned with an IP address automatically.

To connect to a camera, use a device or software such as NDI Studio Monitor to access the camera and confirm the IP address of the camera.

If the connected network does not support DHCP, the camera will take 30 seconds to assign the default IP address **192.168.100.150.**

The computer that will access the camera must be connected to the same network and proper IP address, subnet mask, and default gateway must be assigned to the computer.


Open a web browser and enter the IP address of the camera.
http://192.168.100.150 (default IP address if DHCP is not used)

Chapter 4: Web Interface Settings



Default login user name is **admin**
Password is **9999**

4.1 Live View





Main stream and sub stream buttons for live view image (within the web browser) stream quality set from **Stream Encoding menu**

4.1.1 Exposure




Exposure Mode: Select exposure mode (Auto, Manual)

Gain: Select gain level when Manual mode is selected (0 – 30dB)

Shutter: Select shutter speed value when Manual mode is selected (1/30 – 1/10000)

Anti-Flicker: Enable anti flicker when image flickers (50Hz, 60Hz)

4.1.2 White Balance




WB Mode: Select white balance mode (Auto, Indoor, Outdoor, One Push, ATW, Manual, Temperature)

Red Gain: Adjust red gain level when Manual mode is selected.

Blue Gain: Adjust blue gain level when Manual mode is selected.

Color Temperature: Select color temperature level when **Temperature Mode** is selected.

4.1.3 Image



Mirror: Enable or disable image mirror

Flip: Enable or disable image flip


BLC: Enable or disable backlight compensation.

D-WDR: Enable or disable Digital Wide Dynamic Range

Day&Night: Insert or remove IR Cut filter. Filter removed during the night mode.

Gamma: Adjust gamma level (0 – 15)

4.1.4 Image Setting



Brightness:
Adjust brightness level (0 – 15)

Saturation:
Adjust saturation level (0 – 15)

Contrast:
Adjust contrast level (0 – 15)

Sharpness:
Adjust sharpness level (0 – 15)


4.1.5 Noise Reduction



2D Noise Reduction: Enable or disable 2D noise reduction.


3D Noise Reduction: Select 3D noise reduction level (Auto, 1 – 4, Off)

4.1.6 Video



VI Framerate: Select VI framerate to adjust the sensor level frame capture. Normally used when experiencing the image lagging. Ideal to match the rate with the output format (25, 30, 50, 60)

4.2 Audio



Audio State: Enable or disable embedded audio.

Encode Mode: Select audio encoding method (AAC, LPCM)

Sample Rate: Select audio sampling rate (16,000, 32,000, 48,000Hz)

Bitrate: Select audio bitrate (32,000, 48,000, 64,000, 96,000, 128,000 bits)

Volume: Adjust audio volume level (0 – 100) Confirm: When audio settings are changed, press confirm to apply changes

4.3 Stream

Encoding setting of the camera and video over IP protocols can be configured from this menu.

4.3.1 Encoding



Stream has **Main** and **Sub Stream** settings.

Encode Mode: Select encoding compression (H.264, H.265)

Profile: Select encoding profile (MP, HP)

RTSP Address: Displays the RTSP address of the camera.

Resolution: Select desired stream format.

Bitrate: Select desired stream bitrate (512 – 32,768)


Bitrate Control: Select bitrate control method (CBR, VBR)

I Frame Interval: Select desired i frame interval (1 – 120)

Confirm: When encoding settings are changed, press confirm to apply changes


Note: ***When NDI HX3 is selected, bitrate, bitrate control and i frame interval will not be available to modify.***

4.3.2 RTMP



RTMP Address: Copy and paste the RTMP destination address in the box.
Stream Key: Copy and paste the stream key provided by the RTMP host.
Enable and Confirm: Click on Enable button and press confirm to enable RTMP stream.
When RTMP stream is properly setup, check mark indicator will appear as shown 
Note: ***When RTMP stream is used on YouTube, audio (from section 4.2) needs to be enabled.***

4.3.3 NDI|HX3



Enable: Enable or disable NDIHX streaming capability

Device Name: Modify device name appears on NDI receiver

Channels: Modify channel name appears on NDI receiver

Group: Modify NDI group name

HX3: Enable or disable NDI HX3. Note: NDI HX3 only supports 1080p50 and 1080p60. Select the proper format before enabling HX3.

Discovery: Enable or disable NDI discovery

Multicast: Enable or disable NDI multicast

Bridge: Enable or disable NDI embedded bridge

-Bridge name (User defined name)

-Server IP (Public IP address from host)


-Server Port (Port number from host)

-Encryption Key (Generated from host)

-Source: device identifier with following format: "Device Name (Channels)"

Confirm: When settings are changed, press Confirm to apply changes

4.3.4 SRT



Mode: Select SRT mode (Listener, Caller, Rendezvous)

Enable: enable or disable SRT

Port: Type the port number used in SRT. Default is 1600

Latency(ms): Set SRT latency in milli seconds

Encryption: Enable or disable stream encryption

Key Length: Select key length (16, 24, 32)

Passphrase: Set passphrase parameter

Main Stream: Displays SRT main stream URL


Sub Stream: Displays SRT sub stream URL

Confirm: When SRT settings are changed, press confirm to apply changes

4.4 System

System menu includes network configuration of the camera, account setting, and NTP

4.4.1 Network



By default, DHCP is enabled. If the network does not support DHCP, 192.168.100.150 will be assigned to the camera 30 seconds after the initial boot up.

DHCP: Select DHCP or Static IP address

IP: Type desired IP address if static IP is used

Netmask: Type subnet mask address if static IP is used

Gateway: Type gateway address if static IP is used

DNS: Type DNS address if static IP is used

HTTP Port: Modify HTTP port number. Default is **80**


RTSP Port: Modify RTSP port number. Default is **554**

RTSP Encrypt: Enable or disable RTSP encryption

VISCA over IP: Modify VISCA over IP port number. Default is **52381**

Confirm: When network settings are changed, press **confirm** to apply changes and reboot the camera

4.4.2 Account




Account: Change username of the camera. Default is admin

Password: Change password of the camera. Default is 9999

Confirm Password: Retype the new password for confirmation

Confirm: When account settings are changed, press **confirm** to apply changes

4.4.3 Time



Time Zone: Select the time zone of the location

NTP Enable: Enable or disable the NTP


NTP Update Interval: Select the interval of NTP update (30m – 24h)

NTP Server Address: Modify the NTP server. Default server is time.nist.gov

NTP Port: Modify NTP port number. **Default is 123**

Confirm: When NTP settings are changed, press **confirm** to apply changes

4.5 Maintenance



Firmware Upgrade: Click the upgrade button to open the file browser and locate the firmware file. Select the file and click Open to start the upgrade process. Do not turn off the camera or browser while an upgrade is in progress.

User Save Settings:

Save: Save the current camera settings to a **config.txt file**

Recall: Recall the saved user settings to the camera

Factory Reset: Reset the camera settings to the factory default settings

Reboot: Reboot the camera to apply major changes

Power:

Standby: Put camera to the standby mode

Wake: Operate the camera from Standby mode

4.6 About

About page displays the current camera version information.

Chapter 5: Upgrade

CV574-WP has two types of upgrades required.

When ISP update is needed, an upgrade can be performed from the Maintenance menu under the web interface.

When major update is required, camera ARM process needs to be updated via USB connection.



1. Flip both 1 and 2 dip switches on the breakout cable to **ON** position.
2. Connect USB A connector from breakout cable to computer.
3. Upgrade software called "NZDownloadTool" is needed to upgrade the ARM processor.
4. Please consult with Marshall Electronics for software and upgrade file.
5. When upgrade is completed, set both dip switches back to Off position.

Warranty

For Warranty information please refer to Marshall website page:
https:marshall-usa.com/company/warranty.php